
Ceramic Ornament Instructions

One-sided

- 1) Place a plain piece of clean paper on the heat press table
- 2) Place the ornament face up on the paper
- 3) Place the transfer on face down on the ornament
- 4) Place a plain piece of clean paper on top of transfer
- 5) Place heat conductive rubber on top
- 6) Heat at 400° 5 ½ - 6 minutes adjusting time as necessary for best results

Two-sided

- 1) Print transfer with front and back image side-by-side
- 2) Place a plain piece of clean paper on the heat press table
- 3) Fold paper around ornament and place on press
- 4) Place a plain piece of clean paper on top of transfer
- 5) Place heat conductive rubber on top
- 6) Heat at 400° for 4½ - 5 minutes on first side
- 7) Immediately flip ornament and continue heating for an additional 4½ -5 minutes on second side adjusting time as necessary for best results